



- Eager to **monitor your cold chain** and have an answer at a glance? Then Halveon T·Stream™ IN is the answer to your request, as it continuously monitors all relevant data.
- The Halveon T·Stream™ IN indicators are specially developed to monitor the cold chain in the **pharmaceutical logistics**.
- As a pre-programmed device the indicator Halveon T·Stream™ IN can be **instantly used** to monitor your temperature sensitive shipments.
- Upon receipt the 3 LED's at the front side of the electronic indicator **gives you a fast and clear status** of the condition of your goods.

### EASY HANDLING

- Press the START button to enable Halveon T·Stream™ IN.
- Insert enabled Halveon T·Stream™ IN in the delivery.
- Remove the device from the delivery, press STOP to disable it.
- Check the status of the led after receiving the goods.



### OPERATING INSTRUCTIONS

- Push **Start/Stop** button for 5 sec and notice **GREEN LED** flashes three times to indicate a successful start.
- Attach the started Halveon T·Stream™ IN to your shipment.
- Push **Start/Stop** button for 5 sec and notice **RED LED** flashes three times to indicate a successful stopping. Check the status after receiving the goods.

**OK** Ok (flash 1 time for every 30 sec)

**UNDER** Low threshold activated (flash 1 time for every 30 sec)

**OVER** High threshold activated (flash 1 time for every 30 sec)

## OPERATING INSTRUCTION

**T·Stream IN™**

180 Days

**WARNING!**  
Temperature Sensitive Shipment

Hi: +50°C / +122°F

Lo: -20°C / -4°F

Start Delay: 0

START 5S STOP 5S

LED indicators

Configuration info

Start/Stop button

Instructions

TO START:  
Push the button 5 seconds  
The **GREEN LED** flashes 3 times = **ACTIVE**

Status	LED	Flashing
Working	Green	1x/30s
Over	Red	1x/30s
Under	Blue	1x/30s

EXP: (MM/YY)

Glue Spot

Barcode label

Expiry Date

### OPERATING INDICATIONS

#### START/STOP

STATUS	ACTION	LED CONFIRMATION
START INDICATOR	5 SEC PUSHING BUTTON	OK LED FLASHING 3 TIMES ●●●
STOP INDICATOR	5 SEC PUSHING BUTTON	ALERT LED FLASHING 3 TIMES ●●●

#### STATUS REQUEST BY PUSHING BUTTON 1 TIME

STATUS	ACTION	LED CONFIRMATION
NOT STARTED	PUSH BUTTON 1 TIME	OK LED+ALERT LED FLASH 1 TIME ●●
RECORDING-OK	PUSH BUTTON 1 TIME	OK LED FLASH 1 TIME ●
RECORDING-LOW ALARM	PUSH BUTTON 1 TIME	BLUE LED FLASH 1 TIME ●
RECORDING-HIGH ALARM	PUSH BUTTON 1 TIME	ALERT LED FLASH 1 TIME ●
RECORDING-HIGH AND LOW ALARM	PUSH BUTTON 1 TIME	BLUE LED AND ALERT LED FLASH 1 TIME ●●
STOPPED-OK	PUSH BUTTON 1 TIME	OK LED FLASH 2 TIME ●●
STOPPED-LOW ALARM	PUSH BUTTON 1 TIME	BLUE LED FLASH 2 TIME ●●
STOPPED-HIGH ALARM	PUSH BUTTON 1 TIME	ALERT LED FLASH 2 TIME ●●
STOPPED-HIGH AND LOW ALARM	PUSH BUTTON 1 TIME	BLUE LED AND ALERT LED FLASH 1 TIME ●●

#### USING NOTES

- Take care of Expiry date
- Don't hold the indicator too long in your hand (false alarm through self-heating)
- Only for disposable use